SIGNATURE
External Printer Connection

Signature provides the capability to view reports on its screen and to print them when connected to an external printer (please note: printer not included).

We recommend to use Kolibri KTP-1000 External Printer for seamless integration, however any compatible external thermal printer will do the job.

Please find the instructions below on how to connect Signature to the external printer.

1. Please connect the RS232 end of the cable that comes with printer to the RS232 port at the back of Signature.

2. The other side of the cable should be connected to the printer.

3. Once the connection is successfully established, ensure that both Signature and the printer are powered on. Proceed to count the stack of bills of various denominations. Upon completion, press PRINT button on display to print the report.

4. Should you encounter any connectivity issues with the printer, feel free to reach out to us at any time via our website at www.kolibriusa.com/faq-signature/.