



BISHOP CALIBRATION

Before using the product for the first time, it is essential to calibrate the unit by following the instructions provided below. For optimal performance, we recommend calibrating the unit at least once a month.

Please keep calibration card for future use.

To calibrate your unit, please follow the steps below:

- 1 Turn on the unit, press and hold the button with the up and down arrows for 3 seconds. The unit will beep and the screen will change (as shown to the right).



- 2 Run the calibration card through the machine as if it is a normal bill. The machine should beep and the screen should change.

- 3 Run the calibration card through the machine at least 3 times to make sure the machine is properly calibrated.

- 4 Once you are finished calibrating, turn the unit off and then on to restart.

