

KOLIBRI AUTOMATIC BILL COUNTER



Bill Loading Procedure


The Kolibri Automatic Bill Counter has been developed to count up to 1,500 bills per minute, which makes it one of the fastest back loading bill counters on the market. Therefore, to avoid jamming, misfeeding or other errors, it's extremely important to use the proper bill loading method. For better results, it's also recommended to not count more than 200 bills at a time.

Kolibri recommends the loading technique as described below:

1. Adjust the bill guides to a size slightly wider (.10" on each side) than the width of the bills in the stack (all US dollar denominations are the same size).
2. Correct or remove the bills if they are severely wrinkled, damaged or folded. Avoid counting bills that are excessively dirty, soiled, folded, curled or with foreign material like clips, bands, etc. Bills such as these can cause the machine to malfunction. Once those bills have been removed square the bill stack as illustrated below.

STEP 1:

Correct or remove the bills that are severely wrinkled, damaged or folded. Square the bill stack.




KOLIBRI AUTOMATIC BILL COUNTER



Bill Loading Procedure


STEP 2:

Place the bill stack on the carrying handle, with the bottom of the stack touching the bill guide plate (as shown in the illustration to the right).



STEP 3:

Flip the bill stack towards the rear of the machine so the stack is now leaning against the bill guide plate. The bills will load automatically (unless in manual mode).



Below is a side view of the bill loading technique. All bills must be between the rollers and the feeding plate to be counted smoothly.,

