K Kolibri

SIGNATURE QUICK START GUIDE

PLEASE READ THIS GUIDE FOR A QUICK AND EASY START OR SCAN THIS QR CODE TO FIND THE VIDEOS!

1. ACCESSORIES

For additional info, refer to Section 1.3 of the User Manual

USER MANUAL	SOFT BRUSH	DUST CLOTH	CALIBRATION CARD	POWER CABLE	PRINTER PAPER ROLL

2. BACK OF UNIT

For additional info, refer to Section 1.5 of the User Manual

- Top Cover
- Power Socket
- Power Switch
- Back Drawer
- USB Port
- RS-232 Port
- SD Card Port

3. DISPLAY

For additional info, refer to Section 1.7 of the User Manual

- Selected Mode
- Selected Currency
- Add Function (activated)
- Preset Quantity

| USD | MIX | ADD | BATCH:100 |

PCS   0 — Number of Bills

$ 0 — Total Value

- Detection ON
- R: 0   Automatic/Manual Start
- Number of Rejects
- Recent Bill Serial Number
- SN: 04-30-2021   16:42
- Time
- Date

4. MODES & FUNCTIONS

For additional info, refer to Section 3 of the User Manual

MIX	Count all mixed denominations of selected currency
SORT	Single denomination counting with the first counted one as reference
COUNT	Count only the number of bills
ADD	Keep track of the total number and value of the multiple stacks of counted bills
BATCH	Allow to select a batch quantity for a specific counting process
DSORT	See Section 3.3 of the Kolibri Signature User Manual for more info.
FACE	See Section 3.5 of the Kolibri Signature User Manual for more info.
ORIENT	See Section 3.6 of the Kolibri Signature User Manual for more info.
VBATCH	See Section 3.7 of the Kolibri Signature User Manual for more info.
AUTO-CURRENCY	See Section 4.5 of the Kolibri Signature User Manual for more info.
MULTI-CURRECNCY	See Section 4.6 of the Kolibri Signature User Manual for more info.

5. BUILT-IN PRINTER

For additional info, refer to Section 5.3 of the User Manual

The Kolibri Signature has a built-in printer on top of the machine and the unit comes preloaded with a roll of printer paper.


1. Lift up the lid to open.

2. Insert paper roll inside.

3. Close lid and leave 1/4" of the paper sticking out.

6. BILL LOADING

For additional info, refer to Section 2.2 of the User Manual

1. Make A Stack
Correct or remove bills that are severely wrinkled, damaged or folded. Square the bill stack.

2. Load The Stack

3. Feed The Bills

7. MAINTENANCE

For additional info, refer to Section 6.1 of the User Manual

To get access to the sensors for cleaning or removing jammed notes, please open the back door as shown above

If you have jams, please turn the knob to adjust the feed gap