

KBR-500

External Printer Connection




The Kolibri KBR-500 provides the capability to view reports on its screen and to print them when connected to an external printer (please note: printer not included).


We recommend to use Kolibri KTP-1000 External Printer for seamless integration, however any compatible external thermal printer will do the job.

Please find the instructions below on how to connect Kolibri KBR-500 to the external printer.

1. Please connect the RS232 end of the cable that comes with printer to the RS232 port at the back of KBR-500.



2. The other side of the cable should be connected to the printer.



KBR-500

External Printer Connection



3. Once the connection is successfully established, ensure that both the Kolibri KBR-500 and the printer are powered on. Proceed to count the stack of bills of various denominations. Upon completion, press PRINT button on display to print the report.
4. Should you encounter any connectivity issues with the printer, feel free to reach out to us at any time via our website at www.kolibriusa.com/faq-kbr500.