

# KCD-1000

## Cleaning Procedure

Dirty sensors can affect the KCD-1000 performance and cause genuine bills to be rejected. It is suggested that the user performs weekly maintenance on the unit to maintain top performance.

### Items Needed

- Soft microfiber cloth
- Soft-bristled brush
- Can of compressed air
- Isopropyl alcohol


### Steps

1. First, make sure the unit is turned off and unplugged
2. Perform the cleaning of each sensor, one step at a time (a to c), and check after each step if this resolves the issue. If it does not, proceed to the next cleaning step
  - a. Wipe away dust with a soft microfiber cloth or a soft-bristled brush
  - b. Clean the sensors using a can of compressed air
  - c. Clean the sensors with a cotton swab *lightly* moistened with isopropyl alcohol – gently wipe the sensors with the swab

Refer to the photos below showing the location of the KCD-1000 sensors. For each sensor, follow the steps as described above.

### Sensors Locations

#### Overview:




1. UV Sensor
2. IR Sensors
3. Magnetic Sensors
4. Start Sensor

# KCD-1000

## Cleaning Procedure


### Infrared (IR) Sensor:

Locate the small square sensor on the upper part of the bill track as shown below.



### Ultraviolet (UV) Sensor:

Locate the 4-part UV sensors as shown below. These pairs of sensors are spaced between the MG Sensors (metal bar).




# KCD-1000

## Cleaning Procedure


### Magnetic (MG) Sensor:

Locate the 2 magnetic sensors, which look like a small metal bar and are found at the top middle of the bill track as shown below.



### Start Sensor:

Locate the 2-part start sensor as shown below. These pair of sensors are seated in the front part of the unit, between the 2 rollers.



**Note:** Several factors can cause a KCD-1000 to not recognize a genuine bill:

- Overly wrinkled, overly creased, and overly worn bills
- Dropping the unit or bumping into the unit during use
- A harsh change in temperature
- Extended period of non-use
- Improper maintenance or lack of preventative maintenance/cleaning

If, after cleaning all sensors, this does not resolve the issue, please see the support section on the Kolibri USA website at [www.kolibriusa.com](http://www.kolibriusa.com), or contact Kolibri Support at [support@kolibriusa.com](mailto:support@kolibriusa.com) for further troubleshooting.